

Aqua Clean

Introduction

Aqua Clean is a customized natural microbial/ enzyme product with specific strains for aqua bio remediation and maintain supreme pond & Lake Biota.

Unique biological formulation that is chosen for 100 % green technology to degrade the toxic organic components and improve water quality.



Composition

Bacillus Spore Blend and microbial carrier

Light grey powder;

Bacteria count $>2 \times 10^{10}$ CFU/g;

Application

Surface water bioremediation Pond Management Aquaculture

Urban river pollution control and remediation

Benefit

- ✓ Effective maintain surface water natural eco balance
- ✓ Naturally restore surface water quality without chemicals
- ✓ Degrades excess organics and enhance COD, BOD, TSS removal
- ✓ Reduce sludge build up
- ✓ Eliminate foul odor at the source.
- ✓ Effective control vibrio, pathogenic bacteria
- ✓ 100% natural, non-toxic and chemical free

Dosage & Method

Dosing 1.5 ppm when initial treatment, once per week, initial treatment period 2 month.

Dosing 1.5 ppm when maintenance treatment, once per month, maintenance period 4 month.

Dissolve with water at 1: 20 ratios; keep settling 2 hrs for activation before dosing

Condition

D.O \geq 2 mg/L, Water temp: 15~45°C, pH: 6 ~ 9, Salinity <30000 mg/L

Caution

Do not mix use with bleach, caustics, disinfectants or other chemicals

Packing and shelf life

2 year shelf life, 1 kg per foil bag, 10 kg per carton, 15 kg per drum.

Storage

Store in cool, dry location, keep out of direct sunshine and moisture. Once opened, should be use it within 30 days to prevent activation. Keep out of reach of children.